

Scaling up of tubular proton ceramic electrolyzers



Marie-Laure Fontaine, Christelle Denonville, Einar Vøllestad, Rune Bredesen (SINTEF)
Ragnar Strandbakke, Truls Norby (UiO)
Jose Serra, Nuria Bausá Martínez, Mateusz Tarach, David Catalan Martinez (CSIC ITQ)
Dustin R. Beeaff, Camilla Vigen (CMS)
Julie Segalini, Delphine Maury (Marion Technologies)



UiO : Universitetet i Oslo




ABENGOA HIDROGENO




High pressure PCE

- Dry Hydrogen
- p_{H_2} is balanced with $p_{H_2O} + p_{O_2}$

Proton Ceramic Electrolyser PCE





Solid oxide electrolyser SOE



Advantages

- Intermediate operating temperature : 400 - 600 °C
- Electrochemical compression: pressurized H₂
- More efficient coupling with renewable sources
(heat, steam, electricity)



Tubular design

- Simpler sealing technology, lower sealing area
- Better stress distribution during transient conditions
- Module design enables to close off a tube / replace it
- Mass scale processes for low cost production
- **!! Challenging current collection!!**



Outlook


- Materials
- Mass scale production routes
- Sealing technologies
- Results on high pressure electrolysis
- Scaling up activity

Materials

- Electrolyte: $\text{BaZr}_{1-x-y}\text{Ce}_x\text{Y}_y\text{O}_{3-\delta}$
(10-20% Y ; 10-20% Ce)
- Cathode: Ni + $\text{BaZr}_{1-x-y}\text{Ce}_x\text{Y}_y\text{O}_{3-\delta}$
- Anode: Oxide + $\text{BaZr}_{1-x-y}\text{Ce}_x\text{Y}_y\text{O}_{3-\delta}$


LSM

Double perovskite
(Ba,Co, Gd, La)



Electrolyte

- $\text{BaZr}_{1-x-y}\text{Ce}_x\text{Y}_y\text{O}_{3-\delta}$ 10-20% Y ; 10-20% Ce
- Ce improves sintering and gb conductivity compared to BZY 😊
- Ce decreases stability compared to BZY 😞
- Grain growth increases specific grain boundary conductivity 😊
- Not trivial to achieve large grains



T. Norby, "Proton conductivity in perovskite oxides", in "Perovskite oxides for solid oxide fuel cells", T. Ishihara, ed., Springer, 2009, ISBN 978-0-387-77707-8.

Solid state reactive sintering (SSRS)



Wet milling of precursor powders:
NiO (sintering additive) + BaCO₃,
Y₂O₃, ZrO₂, CeO₂

Drying of powders in oven

Pressing and sintering

Liquid phase assisted sintering


BZCY based dense pellets
with 1 wt. % NiO @ 1500°C






HT-XRD
E FEG-SEM
Dilatometry
DSC
TGA/DTA

Where is Ni?


Ni in BaNiY₂O₅



Ni is distributed in grains and grain boundaries





9




Stable interstitial Ni position (0.5, 0, 0)

Periodic DFT calculations
4x4x4 (320 atom) supercell
2x2x2 k-point grid


Manufacturing process of half-cells: pilot scale production



Automatic 40 tons extruder with capping, cutting systems and air lifted conveyor belt




Automatic spray-coater for 40 cm long sample (batch of 6 samples)




- Three processing steps
- One co-sintering step
- BaSO_4 instead of BaCO_3
- Lower CO_2 emissions
- Lower cost

Half-cells before and after reduction




40 μm

Sintered cell




40 μm

Sintered reduced cell




10 microns

Hg-porosimetry



Between 27-32 vol% porosity (with 60 vol% Ni)

Steam electrode materials






Conditions:

Total P= 3 bar



Steam 75%

T = 700 °C





Manufacturing

- Dip-coating in oxide based suspensions (water or alcohol)
- Drying in air
- Annealing in air




Sealing technology




Det HV Mag WD Pressure
SSD 15.0 kV 126x 11.8 mm

500 μ m



Complete cells

- Testing in ProboStat™
- Cells sealed towards alumina riser
 - Sealing technology developed by CTMS
- In-situ reduction



Cell Area:
5- 11 cm²






Performance

Anode	Current collector	Anode comp
BGLC-BZCY	Pt	x = 0.5

Conditions:


Total P= 3 bar

Cell Area: 11 cm²



Summary

- Scalable production route
- Faradaic efficiency > 90%
- H₂ production rate > 10 ml/min at 500°C
- Ohmic losses observed during lab scale testing
 - Improvement of electrode + current collection design in progress



Next step

Game changer in high temperature steam electrolysis with novel tubular cells integrated in a 10 kW module for pressurized hydrogen production



- SINTEF AS (coordinator) (Norway)
- CoorsTek Membrane Sciences AS (Norway)
- Agencia Estatal Consejo Superior de Investigaciones Cientificas (Spain)
- CRI EHF (Iceland)
- University of Oslo (Norway)
- MC2 Ingenieria y Sistemas SL (Spain)
- Shell Global Solutions International BV (The Netherlands)



GAMER activities



- Optimisation of cell design and key enabling technologies (seals, interconnects, manifolds)
- Industrial pilot production of tubular cells
- Design and engineering of a pressurized 10 kW electrolyser
- Installation, commissioning and testing of the electrolyser
- Process design, LCA and techno-economic evaluation of the electrolyser integrated in CO₂ to liquid fuels/chemicals plant
- Dissemination and exploitation


Acknowledgments

The research leading to these results has received funding from the European Union's Seventh Framework Programme (FP7/2007-2013) for the Fuel Cells and Hydrogen Joint Technology Initiative under grant agreement n° 621244.

Research Council of Norway for the BIOPCFC project (number 219731/O70)

GAMER is a European research project co-financed by the European Union's Horizon 2020 research and innovation program and the Fuel Cells and Hydrogen Joint undertaking under grant 779486.

Thank you



UiO : Universitetet i Oslo



ABENGOA HIDROGENO

